

## Cockshutt Productie nummers.

### Oliver Model 880

1958.....	60505
1959.....	71640
1960.....	NA
1961.....	111262
1962.....	117640

### Oliver Models 950, 990, and 995

1958.....	530001
1959.....	71245
1960.....	84487
1961.....	110064

### Oliver Model 1800

1960.....	90525
1961.....	111025
1962.....	18344

### Oliver Model 1900

1960.....	90932
1961.....	111028
1962.....	118356

### Cockshutt Model 20

1952.....	101
1953.....	1657
1954.....	2568
1955.....	10001
1956.....	20001
1957.....	30001
1958.....	40001

### Cockshutt Model 30

1946.....	1
1947.....	442
1948.....	6705
1949.....	17370
1950.....	26161
1951.....	28505
1952.....	32389
1953.....	35580
1954.....	35974
1955.....	40001
1956.....	50001

### Cockshutt Model 35

1956.....	1001
1957.....	10001

### Cockshutt Model 40

1949.....	101
1950.....	194

1951.....	4098
1952.....	6886
1953.....	10472
1954.....	11363
1955.....	20000
1956.....	30001
1957.....	40001

### Cockshutt Model 50

1953.....	101
1954.....	1750
1955.....	10001
1956.....	20001
1957.....	30001

### Cockshutt Model 540

1958.....	AM1001
1959.....	AN5001
1960.....	None
1961.....	AP1001
1962.....	AR1001

### Cockshutt Model 550

1958.....	BM1001
1959.....	BN5001
1960.....	BO1001
1961.....	BP1001

### Cockshutt Model 560

1958.....	CM1001
1959.....	CN5001
1960.....	CO7001
1961.....	CP1001

### Cockshutt Model 570

1958.....	DM1001
1959.....	DN5001
1960.....	DO7001

### Cockshutt Model 570

<b>Super</b>	
1961.....	DP1001
1962.....	DR1001

### Cockshutt Model 40D4 and Golden Eagle

1954.....	27001
1955.....	30001
1956.....	40028
1957.....	50001

### Cockshutt Golden Arrow

1956.....	16001
-----------	-------